



Polaris RZR 900 S Trail (2021) Rear Window Installation Instructions

Parts Included:

- (4) 1-3/4" Clamps
- (8) 1" Bolts
- (8) Neoprene Washers
- (8) Nuts

Installation Instructions

1. Remove the Roll bar that connects the rear bumper to the cab of the RZR. This will allow the window to slide into place easily.
2. There are 6 bolts that hold the roll bar in place. (2 up by the roof, 2 by the top of the bed, and 2 by the rear bumper) Once these bolts are removed, take off the roll bar and set it aside.
3. Install the stainless-steel clamps with the straight, flat tab facing the rear of the RZR.
Note: Both clamp tabs will be inside the window, they will not sandwich the window.
4. Line up the pre-drilled holes on the window with the clamps. Install a washer onto the supplied bolts, and then slide the bolts through the rear window and then through the clamps. Hand tighten with the supplied nuts.
5. For added security, line up the window with the mounts intended for the Polaris Click 6 Harnesses and insert the remaining bolts into the upper hole of the Click 6 harness mount. Hand tighten the bolts.
6. Once the window is in place, tighten all nuts and bolts to a snug.
7. After the window is tightened and in place, re-install the roll bar that was taken off earlier. The bar should go on easily, but it is recommended to leave the bolts loose until all 6 bolts are in place, and then tighten.

