

Polaris Pro R Wheel Well Block off Installation Instructions



Parts Included:

- (2) 5mm UHMW Block offs
- (6) Push Pins

1. Reach under the Pro R driver's side back wheel well and place the driver's side block off over the gap, lining up the holes with the factory-drilled holes.
2. Push the pins through the block off into the under carriage. It is easiest to start at the bottom and work to the top.
3. Repeat on the passenger side.



Figure 1: Line up the holes in the block off with the factory-drilled holes



Figure 2: Use 3 pins working from bottom to the top.